
SSI 9002

Digital Converter



For Absolute Encoders With Synchron-Serial-Interface

Instruction Manual



ERMA
Electronic GmbH

Warranty

For delivered products our "Allgemeine Lieferungs- und Zahlungsbedingungen" are effective. In no event ERMA-Electronic or its suppliers shall be liable for any other damages whatsoever (including, without limitation, damages for loss of business profits, business interruption or other pecuniary loss) arising out of or inability to use this product.

All products from ERMA-Electronic are warranted against defective material and workmanship for a period of two (2) years from date of delivery. If it is necessary to return the product to ERMA, the sender is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit. ERMA's warranty does not apply to defects resulting from action of the buyer, such mishandling, improper interfacing, operation outside of design limits, improper repair or unauthorized modification.

Trademarks

All trademarks they are named or portrayed in the text are registered trademarks of its owner. The trademarks are recognized by ERMA-Electronic.

CONTENTS

1. Description	4
2. Safety instructions	4
2.1. Symbol explanation	5
3. Mounting	5
3.1. Place of operation	5
3.2. Mounting of signal converter	5
4. Electrical connections	6
4.1. General instructions	6
4.2. Hints against noisy environment	6
4.3. Connection and pin assignment	7
4.4. Connection of absolute encoder	8
4.5. Connection of digital user inputs	8
4.6. Connection of alarm outputs (relay)	8
4.7. Connection of RS 485 interface	9
4.8. Connection of power supply voltage	9
4.8.1. Supply voltage 18 ... 36 V DC	9
5. Startup procedure	9
6. Pushbuttons- and LED-functions	10
6.1. Function of buttons and LEDs	10
7. Modes	11
7.1. Operation level	11
7.2. Access-code level	12
7.3. Programming level	13
8. Procedure of programming	14
8.1. Changing or controlling parameters	14
8.2. Overview of the programming levels	15
8.3. Programming level for configuration P-00	16
8.3.1. Scaling the display range	18
8.4. Programming level of alarms P-02	19
8.4.1. Alarm output functions	21

8.4.2. Alarm high setpoint	22
8.4.3. Alarm low setpoint	22
8.5. Programming level of serial interface P-04	23
8.5.1. Transmission-Mode	23
8.6. Programming quick reference	24
9. Software functions	26
9.1. Master/Slave-Mode	26
9.2. Zero point adjustment	26
9.2.1. Zero point adjustment by pressing button	26
9.2.2. Zero point adjustment by offset value	28
9.3. Incremental measurement	28
9.4. Direction of rotation	28
9.5. MIN/MAX value detection	29
9.6. Hold function	29
9.7. Display test	30
9.8. Main reset	30
10. Error codes	30
10.1. Encoder not connected "Err01"	30
10.2. Waiting for data input "Err02"	30
10.3. External clock frequency too high "ERR03"	30
11. Technical Specifications	31
11.1. Electrical datas	31
11.2. Mechanical datas	32
11.3. Environmental conditions	32
12. Ordering Information	33
13. Notices	33

1. **Description**

The digital converter Model SSI 9002 is an instrument for monitoring the data of an absolute encoder with **Synchronous-Serial-Interface (SSI)** by programmable alarm points.

Standard hardware

- four relay alarm outputs
- two programmable digital input channels
- three programmable pushbuttons

Standard software

- Programming of encoder datas
- Scaling-factor
- Zero point adjustment
- Offset value
- Display segment test
- Hold function
- MAX/MIN value detection
- Auto-Reset of MAX/MIN value
- Edit of the alarm value during normal measurement
- Display of error messages

Following options are available

- RS485 interface

2. **Safety instructions**

This instrument is produced in accordance with Class II of IEC 348 and VDE 0411. When delivered the instrument has been tested to meet all functions described. Before installing the instrument please read the mounting and servicing instructions. We have no liability or responsibility to customer or any other person or entity with respect to any liability, loss or damage caused or alleged to be caused directly or indirectly by equipment or software sold or furnished by us. Read the installation instruction carefully. No liability will be assumed for any damage caused by improper installation.

Inspect the instrument module carton for obvious damage. Be shure there are no shipping and handing damages on the module before processing. Do not apply power to the instrument if it has been damaged.

ERMA's warranty does not apply to defects resulting from action of the buyer, such as mishandling, improper interfacing, operation outside of design limits, improper repair or unauthorized modifications.

3. Mounting

2.1. Symbol explanation



Caution

Attention

Instruction

Tip

Caution: Will be used at **dangerous for life and health !**

Attention: Will cause **damage**

Instruction: If not noticed, **trouble** may occur

Tip: Useful hints for **better operation**


3. Mounting

3.1. Place of operation

Attention must be payed to the protection against humidity, dust and high temperatures at the place of operation.

3.2. Mounting of signal converter

- through simple snap up at 35 mm rail (DIN EN 50022)



4. Electrical connections

4.1. General instructions

- It is forbidden to plug or unplug connectors with voltage applied
- Attach input and output wires to the connectors only without voltages applied
- Cords must be provided with sleeves
- Attention must be paid that the power supply voltage applied will agree with voltage noticed at the name plate.
- The instrument has no power-on switch, so it will be in operation as soon as the power is connected.



4.2. Hints against noisy environment

All inputs and outputs are protected against noisy environment and high voltage spikes. Nevertheless the location should be selected to ensure that no capacitive or inductive interference can have an effect on the instrument or the connection lines.

It is advisable:




- To use shielded cables.
- The wiring of shields and ground (0V) should be star-shaped.
- The distance to interference sources should be as long as possible. If necessary, protective screen or metal enclosures must be provided.
- Coils of relays must be supplied with filters.
- Parallel wiring of input signals and AC power lines should be avoided.

4. Electrical connections

4.3. Connection and pin assignment

All inputs and outputs are connectors, designed as plug-in screw terminals.




Pin assignment:


1	Power supply DC (+)	14	SSI-Signalinput, Clock (+)
2	Power supply DC (-)	15	SSI-Signalinput, Clock (-)
3	Ground connection	16	SSI-Signalinput, Data (+)
4	Option RS 485, A(+)	17	SSI-Signalinput, Data (-)
5	Option RS 485, B(-)	18	SSI-Signalinput, GND (0 V)
6/7	Alarm (relay) output 4	19	Ground connection
8/9	Alarm (relay) output 3	24	Digital user input 1
10/11	Alarm (relay) output 1	25	Digital user input 2
12/13	Alarm (relay) output 2	26	Digital GND

4. Electrical connections

4.4. Connection of absolute encoder



4.5. Connection of digital user inputs




Digital input 1

- active => Connecting Screw Terminal 24 to 26
- Connecting to Ground, low active


Digital input 2

- active => Connecting Screw Terminal 25 to 26
- Connecting to Ground, low-activ

4.6. Connection of alarm outputs (relay)




4.7. Connection of RS 485 interface



4.8. Connection of power supply voltage

4.8.1. Supply voltage 18 ... 36 V DC



5. Startup procedure

Attention must be paid that the power supply voltage applied will agree with the voltage noticed at the name plate. Switch the power supply on (supply voltage applied to screw terminal 1 and 2). After about 2 seconds the display will indicate the applied input signal.




When delivered, the instrument is programmed with a standard configuration (default values). By programming the customer can change the standard configuration according to his measuring task.



Attention ! When the instrument is built in a machine and the customer wants to change the configuration, attention must be paid, that no damage will occur to the machine!

6. Pushbuttons- and LED-functions

There are four push buttons in the front. These push buttons can have different functions. The functions of the push buttons can be used for programming and for service.



6.1. Function of buttons and LEDs

LED 1	LED 2	LED 3	Description
x	x	off	encoder- or hold value is displayed
x	x	red	MIN value is displayed
x	x	green	MAX value is displayed
x	x	green/flashes	programming mode is activated
x	off	x	alarm 2 is not activated
x	lights	x	alarm 2 is activated
x	flashes	off	alarm point 2 is displayed
x	flashes	green/flashes	alarm point 2 is changed
off	x	x	alarm 1 is not activated
lights	x	x	alarm 1 is activated
flashes	x	off	alarm point 1 is displayed
flashes	x	green/flashes	alarm point 1 is changed

x = state of the LED is not considered

7. Modes

The operation and the programming of the panel meter is organized in several states:

- Operation level
- Access-code level
- Programm level

7.1. Operation level

In the state “operation level” the normal functions of the instrument are activated. A normal measurement cycle looks like below:

- Read the value of encoder, calculate and display
- Evaluate the digital inputs
- Alarm outputs and serial interface

Dependent on the programming of the parameter **0-14** (function of key ), **0-15** (function of key ) and **0-13** (function of key ), following key-functions are available in the operation level.

Parameter 0-13 Function of pushbutton “*”	
By pressing	
0	No function
1	Reset the MIN/MAX value
2	Taring
3	Clear tara value
4	Incremental measurement
5	Manual reset of alarms
6	start single serial transmission

Parameter 0-14 Function of pushbutton “-”		
By pressing	Pressing during 3 sec.	
0	No function	-
1	Display value of encoder	-
2	Display MAX value	-
3	Display MIN value	-
4	Display hold value	-
5	Display alarm point 1	Change alarm point 1
6	Display alarm point 2	Change alarm point 2

7. Modes

Parameter 0-15 Function of pushbutton “+”		
	By pressing	Pressing during 3 sec.
0	No function	-
1	Display value of encoder	-
2	Display MAX value	-
3	Display MIN value	-
4	Display hold value	-
5	Display alarm point 1	Change alarm point 1
6	Display alarm point 2	Change alarm point 2

7.2. Access-code level

The state “access-code level” becomes active by pressing the pushbutton  during the state “operation level”. The display shows “c000”. During the state “access-code level” the normal functions of the instrument are active.

pushbutton	Function
	Confirm of the displayed access-code
	Increase the access-code
	Decrease the access-code
	Programmed function

7.3. Programming level

The state "programm level" becomes active by entering the right access-code. The access-code must be confirm by pressing the pushbutton  . The programming is organized in following steps:

- Selection of a programming level
- Selection of a parameter
- Change of the selected parameter

Pushbutton	Press	Pressing during 3 sec.
	Selection of - Programming level - Parameter	-
	Decrease of - Programming level - Number of parameter - Value of parameter	-
	Increase of - Programming level - Number of parameter - Value of parameter	-
	-	Break the programming routine

8. **Procedure of programming**

The procedure of programming is organized in several different steps.

Access to the selection of the programming levels

- Pressing pushbutton  => access-code enter is active
- The display shows "c000"
- Changing the access-code by pressing the pushbutton  or  and confirm the changed access-code by pressing the pushbutton 

If the entered access-code is not correct, the instrument will jump back to the state "operation level".

8.1. **Changing or controlling parameters**

Activating the programming routine

- Pressing pushbutton 
- LED 3 flashes green
- The display shows "c000"
- Changing the access-code by pressing the pushbutton  or 
- Confirm access-code by pressing the pushbutton 
- The display shows "P-00"

Leaving the programming routine

- Pressing the pushbutton  or  until the display shows "PEnd"
- Confirm the display "PEnd" by pressing the pushbutton 
- LED 3 is off
- The active state of the panel meter is "operation level"

Selection of the programming level

- Selecting the programming level by pressing the pushbutton  or 
- Confirm the programming level by pressing the pushbutton 
- The display shows the number of the parameter of the selected programming level
For example: "0-00" => parameter 0 of the programming level 0
For example: "2-00" => parameter 0 of the programming level 2

Leaving the programming level

- Pressing the pushbutton or until the display shows “xEnd”
For example: “0End” => leaving programming level 0
For example: “2End” => leaving programming level 2
- Confirm the display “xEnd” by pressing the pushbutton
- The display shows the programming level
For example: “P-00” => for programming level 0
For example: “P-02” => for programming level 2

Selection of the parameter

- Selection the parameter by pressing the pushbutton or
- Confirm the parameter by pressing the pushbutton
- The display shows the last programmed value of the selected parameter

Change and controll the selected parameter

- Change the value of the parameter by pressing the pushbutton or
- Confirm the value of the parameter by pressing the pushbutton
- The display shows the programming level and the number of the parameter
For example: “0-05” => parameter number 5 of programming level 0
For example: “2-08” => parameter number 8 of programming level 2

8.2. Overview of the programming levels

The parameters of the panel meter are organized in different programming levels.

P-00: Programming level for configuration of the panel meter

The configuration is used to adapt the absolute encoder and the panel meter.

P-02: Programming level for the alarms

This programming level is used to programm all settings for the alarm outputs.

P-04: Programming level of the serial interface

This programming level is used to programm the address and baud rate of the serial interface.

8.3. Programming level for configuration P-00

Param.	Description	Setting range	Default value
0-00	Resolution (Bits)	10 .. 25	12
0-01	Output code 0 -> Gray 1 -> Binary	0 .. 1	0
0-02	Master/Slave-Mode 0 -> Instrument = Master 1 -> Instrument = Slave	0 .. 1	0
0-03	Clock for Master-Mode 0 -> Frequency = 200 kHz 1 -> Frequency = 100 kHz	0 .. 1	0
0-04	Zero adjustment 0 -> Zero adjustment without sign 1 -> Zero adjustment with ± display	0 .. 1	0
0-05	Counting direction 0 -> increasing clockwise rotation 1 -> increasing anticlockwise rotation	0 .. 1	0
0-06	Scalingfactor	0.00001 .. 9.99999	1.00000
0-07	Offset value	-99999 .. 999999	0
0-08	Programmable decimal points 0 -> XXXXXX 1 -> XXXXX.X 2 -> XXXX.XX 3 -> XXX.XXX 4 -> XX.XXXX 5 -> X.XXXXX	0 .. 5	0
0-09	Data source of the display 0 -> Encoder value 1 -> MAX value 2 -> MIN value 3 -> Hold value	0 .. 3	0
0-10	Reset time of the MIN/MAX value 0 -> No automatically reset X -> Reset time in seconds	0 .. 100	0
0-11	Function of digital user input 1 0 -> No function 1 -> Reset MIN/MAX value 2 -> Taring of encoder 3 -> Clear tara value of encoder 4 -> Incremental measurement 5 -> Manual reset of alarms 6 -> Hold function	0 .. 11	0

8. Procedure of programming

0-11	continue of 0-11: 7 -> Display test 8 -> Display value of encoder 9 -> Display MAX value 10 -> Display MIN value 11 -> start single serial transmission	0 .. 11	0
0-12	Function of digital user input 2 0 -> No function 1 -> Reset MIN/MAX value 2 -> Taring of encoder 3 -> Clear tara value of encoder 4 -> Incremental measurement 5 -> Manual reset of alarms 6 -> Hold function 7 -> Display test 8 -> Display value of encoder 9 -> Display MAX value 10 -> Display MIN value 11 -> start single serial transmission	0 .. 11	0
0-13	Function of push button “*” 0 -> No function 1 -> Reset MIN/MAX value 2 -> Taring of encoder 3 -> Clear tara value of encoder 4 -> Incremental measurement 5 -> Manual reset of alarm 6 -> start single serial transmission	0 .. 6	0
0-14	Function of pushbutton “-” 0 -> No function 1 -> Display value of encoder 2 -> Display MAX value 3 -> Display MIN value 4 -> Display hold value 5 -> Display/change alarm point 1 6 -> Display/change alarm point 2	0 .. 6	0
0-15	Function of pushbutton “+” 0 -> No function 1 -> Display value of encoder 2 -> Display MAX value 3 -> Display MIN value 4 -> Display hold value 5 -> Display/change alarm point 1 6 -> Display/change alarm point 2	0 .. 6	0
0-16	Access-code	0 .. 999	0
0End	Leaving programming level 0		

8.3.1. Scaling the display range

The scaling of the display range is matched by using a scaling-factor and an offset value. The calculation of the display value looks like below:

$$\text{Display} = (\text{Enc_value} - \text{Zero_adjustmet}) \times \text{Sca_faktor} + \text{Offset value}$$

The overflow or underflow becomes active, if the displayed value is greater than 999999 or smaller than -99999.

- When **overflow** is activ the display shows “nnnnnnn”
- When **underflow** is active the display shows “uuuuuuu”

8.4. Programming level of alarms P-02

Param.	Description	Setting range	Default value
2-00	Alarm output 1, data source 0 -> Alarm 1 off 1 -> Alarm 1 to value of encoder 2 -> Alarm 1 to maximum value 3 -> Alarm 1 to minimum value 4 -> Alarm 1 to hold value	0 .. 4	0
2-01	Alarm output 1, high or low 0 -> Contact closed by low limit 1 -> Contact closed by high limit 2 -> Contact open by low limit 3 -> Contact open by high limit	0 .. 3	0
2-02	Alarm output 1, alarm point	-99999 .. 999999	0
2-03	Alarm output 1, hysteresis	1 .. 1000	1
2-04	Alarm output 1, release delay time in seconds	0 .. 60	0
2-05	Alarm output 1, operate delay time in seconds	0 .. 60	0
2-06	Alarm output 2, data source 0 -> Alarm 2, off 1 -> Alarm 2 to value of encoder 2 -> Alarm 2 to maximum value 3 -> Alarm 2 to minimum value 4 -> Alarm 2 to hold value	0 .. 4	0
2-07	Alarm output 2, high or low 0 -> Contact closed by low limit 1 -> Contact closed by high limit 2 -> Contact open by low limit 3 -> Contact open by high limit	0 .. 3	0
2-08	Alarm output 2, alarm point	-99999 .. 999999	0
2-09	Alarm output 2, hysteresis	1 .. 1000	1
2-10	Alarm output 2, release delay time in seconds	0 .. 60	0
2-11	Alarm output 2, operate delay time in seconds2 ->Alarm	0 .. 60	0
2-12	Alarm output 3, data source 0 ->Alarm 3 off 1 ->Alarm 3 to value of encoder see next page		

8. Procedure of programming

Param.	Description	Setting range	Default value
2-12	2 -> Alarm 3 to maximum value 3 -> Alarm 3 to minimum value 4 -> Alarm 3 to hold value	0 .. 4	0
2-13	Alarm output 3, high or low 0 -> Contact closed by low limit 1 -> Contact closed by high limit 2 -> Contact open by low limit 3 -> Contact open by high limit	0 .. 3	0
2-14	Alarm output 3, alarm point	-99999 .. 999999	0
2-15	Alarm output 3, hysteresis	1 .. 1000	1
2-16	Alarm output 3, release delay time in seconds	0 .. 60	0
2-17	Alarm output 3, operate delay time in seconds	0 .. 60	0
2-18	Alarm output 4, data source 0 -> Alarm 4, off 1 -> Alarm 4 to value of encoder 2 -> Alarm 4 to maximum value 3 -> Alarm 4 to minimum value 4 -> Alarm 4 to hold value	0 .. 4	0
2-19	Alarm output 4, high or low 0 -> Contact closed by low limit 1 -> Contact closed by high limit 2 -> Contact open by low limit 3 -> Contact open by high limit	0 .. 3	0
2-20	Alarm output 4, alarm point	-99999 .. 999999	0
2-21	Alarm output 4, hysteresis	1 .. 1000	1
2-22	Alarm output 4, release delay time in seconds	0 .. 60	0
2-23	Alarm output 4, operate delay time in seconds	0 .. 60	0
2End	Leave programming level P-02		

8.4.1. Alarm output functions

Data sources of the alarms:

- Value of the encoder
- Maximum value
- Minimum value
- Hold value

Indication of alarms

- Two relay output
- LED 1 and LED 2 at the front

Programmable functions of the alarms

- Alarm value
- Hysteresis
- Release delay time and operate delay time
- High or low alarm

Manual alarm reset

In dependence of programming the digital inputs and the functional pushbutton  is the alarm output latched or not latched.

Alarm output latched:

- If the digital input 1, 2 (parameter 0-11 and 0-12) or the functional pushbutton  (parameter 0-13) is programmed to manual alarm reset
- Reset the latched alarm output by activate the digital inputs or press the functional pushbutton 

Alarm output not latched:

- If the digital inputs and the functional pushbutton  are not programmed to manual alarm reset

Display and edit the alarm values 1, 2, 3, and 4.


- Inside the programmig routine, which is reached over the enter code. During the programming routine no measurement is taken.

Display and edit the alarm values 1, and 2.


- Outside the programming routine by pressing the pushbutton  or  during normal measurement are taken.

The edition is end when pressing the pushbutton  . Therfore the alarm value will be up to date.

8.4.2. Alarm high setpoint



8.4.3. Alarm low setpoint



8.5. Programming level of serial interface P-04

The parameters of the programming level P-04 exists only by panel meters with the option serial interface. The interface moduls are bidirectional and works at the slave mode.

Param.	Description	Setting range	Default values
4-00	Interface address	0 .. 31	1
4-01	Interface baud rate 0 -> : 300 baud 1 -> : 600 baud 2 -> : 1200 baud 3 -> : 2400 baud 4 -> : 4800 baud 5 -> : 9600 baud 6 -> : 19200 aud	0 .. 6	6
4-02	Transmission-Mode 0 -> PC-Mode 1 -> Terminal-Mode timer controlled 2 -> Terminal-Mode button/input controlled	0 .. 2	0
4-03	Sendrate in sec. 0 -> permanent transmission	0 .. 3600	0
4-04	Data source for serial interface 0 -> Value of encoder 1 -> MAX value 2 -> MIN value 3 -> Hold value	0 .. 3	0
4End	Leave programming level P-04		

The meter can be controlled completly with the serial interface. That means the panel meter can initialized of a host (unit name, revision number). It can be adjust all parameters and it can be read all measured values resp. all values of the parameters.


8.5.1. Transmission-Mode

PC-Mode

In PC-Mode a single transmission is started with a special command from the PC. A complete list of all possible commands is available as additional manual.


8. Procedure of programming

8.6. Programming quick reference



8. Procedure of programming

description
P = P - pressing the button
+ = - pressing the button
- = - pressing the button



9. Software functions

9.1. Master/Slave-Mode

Master-Mode

Parameter 0-02 have to be programmed to 0

For reading the value of the encoder the clock is generated by the instrument. The clock frequency can be programmed to 100 kHz or 200 kHz. (parameter 0-03)

Slave-Mode:

Parameter 0-02 have to be programmed to 1

The clock signal have to be generated by an other instrument. The data transmission between the encoder and the instrument dependent on this "external clock".

In slave mode attention should be paid to:

- External clock may not exceed 125 kHz
- Pause of clock brushes have to be min. 500 µs
- The encoder value will be displayed with 28 values per second



9.2. Zero point adjustment

Sometimes an exactly mechanical zero point adjustment isn't possible. But it's possible to adjust the zero point by software.

9.2.1. Zero point adjustment by pressing button

The zero point can be changed by pressing the button. Parameter 0-13 have to be programmed to 2.


1. Zero point adjustment with sign:

Parameter 0-04 have to be programmed to 1

Example:

Absolute Encoder SSI-Encoder, singeltur'n


Resolution: 4096 steps per rotation



Display range without changing of the zero point

Display range with changing of the zero point

The pushbutton  have been pressed by a display of 2048




2. Zero point adjustment without sign: Parameter 0-04 have to be programmed to 0

Example:


Absolute Encoder SSI-Encoder, singleturn
Resolution: 4096 steps per rotation

Display range without changing of the zero point



Display range with changing of the zero point

The pushbutton  have been pressed by a display of 2048



9.2.2. Zero point adjustment by offset value

The calculation of the programmed offset value (parameter 0-07) looks like below:

$$\text{Display} = (\text{Enc_value} - \text{Zero_adjustmet}) \times \text{Sca_faktor} + \text{Offset value}$$

There can be a \pm display, as a result of programming an offset value.

Attention should be paid to:



- The charging of the offset value is followed after the charging of the scaling-factor.
- The Parameter 0-04 have to be programmed to 1

9.3. Incremental measurement

A relative measurement can be made by using the incremental measurement function. Activating the incremental measurement function will happen, that a incremental measurement value will be stored to a non-volatile EEPROM even after switching of the instrument.

Activating the incremental measurement function

- The digital input 1 (parameter 0-11)
- The digital input 2 (parameter 0-12)
- The functional pushbutton (parameter 0-13)

Activating the incremental measurement function by pressing the functional pushbutton or activating digital input 1/digital input 2 (dependent on the programming of the parameter 0-11, 0-12 and 0-13), cause that the current encoder value is stored to an EEPROM. This value will be subtracted from each current encoder value.

Activating the function a second time will switch off the function and clear the incremental measurement value of the EEPROM.

9.4. Direction of rotation

The direction of rotation can be changed by software function. The encoder will usually count in increasing direction, if the driving shaft turns with clockwise rotation (top view at the driving shaft).

**Increasing values with clockwise rotation (top view at the driving shaft),
Parameter 0-05 have to be programmed to 0**

**Increasing values with anti-clockwise rotation (top view at the driving shaft),
Parameter 0-05 have to be programmed to 1**

9.5. MIN/MAX value detection

The panel meter include a MIN/MAX value detection. The maximum and minimum value can be displayed with the frontal push buttons or the digital user inputs. Besides the maximum and minimum value can be controlled of the alarm output or can be used as the data source for the analog output

Reset the minimum and maximum values:

- Automatically by the programmed memory reset time (parameter 0-10)
- By activating the digital inputs 1 or 2 (parameter 0-11 and 0-12)
- By pressing the functional pushbutton  (parameter 0-13)
- By leaving the programming routine
Display the minimum and maximum value
- By programming as data source of the display (parameter 0-09)
- By activating the digital input 1 or 2 (parameter 0-11 and 0-12)
- By pressing the pushbutton  or  (parameter 0-15 and 0-14)

Indication of the displayed minimum and maximum value

- LED 3 lights red => minimum value is displayed
- LED 3 lights green => maximum value is displayed

9.6. Hold function

When activating the hold function the value of the data source, which is programmed in parameter 0-09, is taken over into the hold memory. If the hold function is not active the hold value is the same as the value of the data source, which is programmed in parameter 0-09.

Activating the hold function by:

- Digital input 1 (parameter 0-11)
- Digital input 2 (parameter 0-12)

Reset the hold value

- By leaving the programming routine

Display the hold value by

- Programming as data source of the display (parameter 0-09)
- Pressing the pushbutton  or  (parameter 0-15 and 0-14)

The hold value can:

- Show on display
- Watched by alarm output
- Set to the analog output

9.7. **Display test**

When activating the display test all segments of the display are light on. The display shows “**8.8.8.8.8.8.**”

Activating the display test by:

- Digital input 1 (parameter 0-11)
- Digital input 2 (parameter 0-12)

9.8. **Main reset**

The main reset is performed by pressing a key combination at the front of the panel meter. By doing this all parameters are setting to the default value. The value of the parameter 0-00 (input range) is not changing by the main reset.

During the main reset the display shows “Init.”.

Perform the main reset by

Pressing the pushbuttons  ,  and  at the same time during 10 seconds.

10. **Error codes**

10.1. **Encoder not connected “Err01”**

- The display flashes and indicate “Err01”
- Signalizes that no encoder have been connected to the instrument

10.2. **Waiting for data input “Err02”**

- The display flashes and indicate “Err02”
- Signalizes in slave-mode, that after the connection of an encoder no data input have been received by the instrument.

10.3. **External clock frequency too high “ERR03”**

- The display flashes and indicate “Err03”
- Signalizes in slave mode, that the clock frequency of the “external clock” is too high (> 125 kHz).

11. Technical Specifications

11.1. Electrical datas

SSI signal input

Resolution	: singleturn or multiturn
Code	: 10 .. 25 bit
Clock output	: binary or gray
Clock input	: driver RS 422/485
Data input	: receiver RS 422/485

Master mode

Clock frequency	: internal, 100 kHz or 200 kHz
Conversion rate	: approximate 28 values/second

Slave mode

Clock frequency	: external, max. 125 kHz
Break of clock brushes	: min. 500 µs
Conversion rate	: approximate 28 values/second

Digital user inputs

Logic	: 10 kΩ to +5 V
Signal level	: NPN, max. 30 V

Alarm outputs

Signaling	: L-Pegel < 0,4 V
Switch voltage	: H-Pegel > 3,5 V
Switch current	: 4 relays (programmable as opened contact or closed contact)
Switch power	: 2 LEDs at the front

Option interface

Protocol	: RS 485
Baud rate	: DIN 66019 / ISO 1745
Data format	: 300, 1200, 2400, 4800, 9600, 19200

Power supply DC

Power consumption	: 18 .. 36 V DC
Isolation voltage	: approx. 200 mA

Isolation voltage	: 500 V / 1 min
-------------------	-----------------

11.2. Mechanical data

Display	: 6 decades, 8 mm, red : decimal point programmable : preliminary zero suppression : - sign at negative values
Operation, keyboard design	: front membrane with push buttons
Case	: rail mounting DIN EN 50022 : 35 mm snap in : 67,5 x 75 x 105 mm
Dimensions (W x H x D)	: approx. 300 g
Weight	: plug-in screw terminal
Connection	: max. □ 2,5 mm ²

11.3. Environmental conditions

Operating temperature	: 0 .. 50 °C
Storage temperature	: -20 .. 70 °C
Humidity	: < 80 %, not-condensing
Protection	: protection class II
Front protection	: IP 40
Field of application	: connectors IP 20 : class 2 : overvoltage protection II
CE	: in conform with 89/336/EWG : NSR 73/23/EWG

ERMA - Electronic GmbH

Max-Eyth-Straße 8

D-78194 Immendingen

Phone +49 7462 2000-0
Fax +49 7462 2000-29
email info@erma-electronic.com
web www.erma-electronic.com

